

SPEED
REDEFINED



CBR 500R



500^{cc} DOHC

PARALLEL TWIN – CYLINDER ENGINE

WITH ASSIST/SLIPPER CLUTCH

SPECIFICATIONS

DIMENSION

Dimension 2.081 x 758 x 1.145 mm | Fuel Tank Capacity 17,1 L | Ground Clearance 130 mm | Curb Weight 192 kg | Seat Height 789 mm | Wheel Base 1.409 mm

ENGINE

Engine Type Liquid-Cooled, 4-Stroke, DOHC Parallel Twin Cylinder | Displacement 471,03 cc | Fuel Supply System PGM-FI (Programmed Fuel Injection System) | Bore x Stroke 67 x 66,8 mm | Compression Ratio 10,7 : 1 | Max. Power 37 kW/8.500 rpm | Max. Torque 44,6 Nm/6.500 rpm | Transmission Constant mesh, 6 Speed | Starting System Electric | Clutch System Wet, Multiple with Coil Spring | Oil Capacity 2,5 L (Periodic Exchange)

FRAME

Frame Type Diamond, Steel | Front Tires 120/70ZR17M/C (58W) | Rear Tires 160/60ZR17M/C (69W) | Front Brake Hydraulic, Single 320 mm Wavy Disc with Two Piston Calipers | Rear Brake Hydraulic, Single 240 mm Wavy Disc with Single Piston Caliper | Brake System ABS 2 Channel | Front Suspension Showa, 41 mm Telescopic Fork, Adjustable | Rear Suspension Swing Arm, Adjustable Showa Monoshock with ProLink

ELECTRICAL

Ignition Type Full Transisterized, Battery | Spark Plug Type NGK CPR8EA-9 | Front Headlight Hi 6,4 W x 2 (LED) | Rear Headlight Low 3,8 W x 2 (LED)

AVAILABLE COLORS



GRAND PRIX RED



MAT AXIS GRAY METALLIC



NEW
SUPER-AGGRESSIVE
SPORT STYLE



NEW LCD
INSTRUMENT DISPLAY



FULL LED
LIGHTING SYSTEM



EXHILARATING
EXHAUST NOTE



HONDA
ABS BRAKES:
WAVE PATTERN DISC FRONT & REAR



ADJUSTABLE
FRONT & REAR
SUSPENSION

CBR500R



#CARI_AMAN
saat naik motor

Gunakan selalu helm, pasang tali pengikat dan kencangkan secara benar.

Gunakan jaket lengan panjang dan sarung tangan yang dirancang untuk keselamatan dan kenyamanan berkendara.

Pakaihlah celana panjang yang pas dan nyaman serta gunakan sepatu untuk kestabilan saat kaki berpijak.

EXCLUSIVE AT
Honda BigWing

CONTACT CENTER
1-500-989
0811-9-500-989
customercare@astra-honda.com

Jakarta, Bandung, Semarang, Yogyakarta, Surabaya, Bali, Banjarmasin, Makassar dan Medan
www.hondabigbike.id
www.astra-honda.com

Cara perawatan yang aman:

- Periksa tinggi permukaan oli dan gunakan selalu AHM Oil.
- Periksa rem dan tekanan udara ban.
- Gunakan selalu Honda Genuine Parts, suku cadang asli sepeda motor Honda, yang didistribusikan oleh PT Astra Honda Motor.
- Lakukan perawatan teratur di bengkel-bengkel Honda BigWing.



Dibantu oleh
PT Astra Honda Motor



AHM Oil Asli Motor Honda



Suku Cadang Asli Motor Honda



PT Astra Honda Motor



SARETU.HONDASID

