

FROM
**BOREDOM
TO THRILL**
AT THE FIRST SIGHT





650^{cc} DOHC

INLINE FOUR – CYLINDER ENGINE

WITH ASSIST/SLIPPER CLUTCH

SPECIFICATIONS

DIMENSION

Dimension 2.128 x 784 x 1.076 mm | Fuel Tank Capacity 15,4 L | Ground Clearance 148 mm | Curb Weight 203 kg | Seat Height 810 mm | Wheel Base 1.449 mm

ENGINE

Engine Type Liquid-Cooled, 4-Stroke, DOHC Four Cylinder | Displacement 648,72 cc | Fuel Supply System PGM-FI (Programmed Fuel Injection System) | Bore x Stroke 67 x 46 mm | Compression Ratio 11,6 : 1 | Max. Power 66,5 kW/11.000 rpm | Max. Torque 60,7 Nm/8.000 rpm | Transmission Constant mesh, 6 Speed | Starting System Electric | Clutch System Wet, Multiple with Coil Spring | Oil Capacity 2,3 L (Periodic Exchange)

FRAME

Frame Type Diamond, Steel | Front Tires 120/70R17M/C (58W) | Rear Tires 180/55ZR17M/C (73W) | Front Brake Hydraulic, Double 310 mm Disc with Four Piston Calipers | Rear Brake Hydraulic, Single 240 mm Disc with Single Piston Caliper | Brake System ABS 2 Channel | Front Suspension Showa, 41 mm Inverted Telescopic Fork | Rear Suspension Aluminum Swing Arm, Adjustable Monoshock

ELECTRICAL

Ignition Type Full Transisterized, Battery | Spark Plug Type NGK IMR9E-9HES | Front Headlight Hi 9,3 W x 1 (LED) | Rear Headlight Low 9,3 W x 1 (LED)

AVAILABLE COLORS



CANDY CHROMOSPHERE RED




Graphite BLACK




NEO SPORTS CAFÉ DESIGN



INVERTED TELESCOPIC FRONT FORK




HSTC Honda SELECTABLE TORQUE CONTROL



NEW LCD INSTRUMENT DISPLAY



FULL LED LIGHTING SYSTEM



ABS BRAKES WITH FLOATING DISC



Gunakan selalu helm, pasang tali pengikat dan kencangkan secara benar.

Gunakan jaket lengan panjang dan sarung tangan yang dirancang untuk keselamatan dan kenyamanan berkendara.

Pakailah celana panjang yang pas dan nyaman serta gunakan sepatu untuk kestabilan saat kaki berpijak.



CONTACT CENTER
1-500-989
0811-9-500-989
customercare@astra-honda.com

Jakarta, Bandung, Semarang, Yogyakarta, Surabaya, Bali, Banjarmasin, Makassar dan Medan
www.hondabigbike.id
www.astra-honda.com

Cara perawatan yang aman:

- Periksa tinggi permukaan oli dan gunakan selalu AHM Oil.
- Periksa rem dan tekanan udara ban.
- Gunakan selalu Honda Genuine Parts, suku cadang asli sepeda motor Honda, yang didistribusikan oleh PT Astra Honda Motor.
- Lakukan perawatan teratur di bengkel-bengkel Honda BigWing.

